









0108



Positionsnr	Ersatzteilnummr	Ersatz	Beschreibung
0101	12029659		Antrieb
0102	12029658		Mixeraufsatz
0103	00657243		Messbecher
0104	00630718		Deckel
0107	00753478		Getriebe
0108	00753480		Universalzerkleinerer
0110	00630938		Deckel
0114	00152047	10000212	Gummifuss
0115	00611304	00416533	Messer
8000	00753479		Passierstab
8001	00753480		Universalzerkleinerer
8002	12027396		Universalzerkleinerer
8003	00753124		Rührbesen
8012	12028091		Bürste
8051	00653180		Tasche
0105	12035538		Motor
0106	10016147		Auswurfhebel
0111	00611303	00167715	Messer
0112	00751402		Becher



Positionsnr	Ersatzteilnummr	Ersatz	Beschreibung
0201	00753481		Getriebe
0202	00753482		Träger
0203	00748750		Becher
0204	00653325		Stößel
0205	00618123		Scheibe
0206	00618102		Scheibe
0207	00622019		Scheibe
0208	00622020		Scheibe
0209	00629987		Messer
0210	00629988		Knethaken
8000	00753479		Passierstab
8001	00753480		Universalzerkleinerer
8002	12027396		Universalzerkleinerer
8003	00753124		Rührbesen
8012	12028091		Bürste
8051	00653180		Tasche
0211	00657378		Rührbesen
0212	00629984		Getriebe
0213	00753124		Rührbesen