


<b>Positionsnr</b>	<b>Ersatzteilnummr</b>	<b>Ersatz</b>	<b>Beschreibung</b>
0101	00753477		Antrieb
0102	00753475		Mixer
0103	00657243		Messbecher
0104	00630718		Deckel
0107	00753478		Getriebe
0108	00753122		Universalzerkleinerer
0110	00630938		Deckel
8012	12028091		Bürste
0105	12035538		Motor
0106	10016147		Auswurfhebel
0111	00629985	00615742	Messer
0112	00647801		Mixbecher
8001	00753122		Universalzerkleinerer
8002	00753124		Rührbesen



<b>Positionsnr</b>	<b>Ersatzteilnummr</b>	<b>Ersatz</b>	<b>Beschreibung</b>
8012	12028091		Bürste
0211	00753229		Vorsatz
0212	00629702		Messer
0213	00629986		Getriebe
0214	00753479		Passierstab
8001	00753122		Universalzerkleinerer
8002	00753124		Rührbesen