







Positionsnr	Ersatzteilnummr	Ersatz	Beschreibung
0101	00753477		Antrieb
0102	00753475		Mixer
0103	00657243		Messbecher
0104	00630718		Deckel
8012	12028091		Bürste
0105	12035538		Motor
0106	10016147		Auswurfhebel
8001	00753122		Universalzerkleinerer
8002	00753124		Rührbesen
8003	00753479		Passierstab



Positionsnr	Ersatzteilnummr	Ersatz	Beschreibung
8012	12028091		Bürste
0205	00635682		Träger
0206	00647801		Mixbecher
0207	12008242		Sieb
0208	00635704		Messer
0209	00753478		Getriebe
0210	00630938		Deckel
0211	12008258		Universalzerkleinerer
0212	00635706	00635680	Messer
8001	00753122		Universalzerkleinerer
8002	00753124		Rührbesen
8003	00753479		Passierstab