












Positionsnr	Ersatzteilnummr	Ersatz	Beschreibung
0201	00633492		Stößel
0202	12004926		Getriebe
0203	12004928		Messer
0204	10012689		Gitter
0205	12030517		Träger
0206	11004139		Becher
0207	12004929		Träger
0208	00633493		Scheibe
0209	00633494		Scheibe
0210	00622019		Scheibe
0211	00633491		Stößel
0212	00633490		Messer
0213	00633489		Knethaken
8000	00753479		Passierstab
8012	12028091		Bürste
0216	00657378		Rührbesen
0217	00629984		Getriebe
0218	00753124		Rührbesen



Positionsnr	Ersatzteilnummr	Ersatz	Beschreibung
0101	12004923		Antrieb
0102	00753475		Mixer
0103	00657243		Messbecher
0104	00630718		Deckel
0107	00753478		Getriebe
0108	00753480		Universalzerkleinerer
0110	00630938		Deckel
0114	00152047	10000212	Gummifuss
8000	00753479		Passierstab
8012	12028091		Bürste
0105	12035538		Motor
0106	10016147		Auswurfhebel
0111	00611303	00167715	Messer
0112	00268636		Mixbecher